

Hardware Included:

- (10) 10-32 x 3/8" Screws A
- (5) 10-11 x 5/8" Screws B
- (2) Barrel Nuts

QUINCAILLERIE INCLUSE
 (10) 10-32 x 3/8" VIS A
 (5) 10-11 x 5/8" VIS B
 (2) ECROUS CYLINDRIQUES

Cornershaper™

FORME DE COIN™

Tools Needed:

- Phillips Head Screwdriver
- Slotted Screwdriver
- 1/8" [3.2mm] Drill Bit

Outils nécessaires

- Tournevis Phillips pour vis à rainures
- 1/8" [3.2mm] bit de forage

27912, 5/27/09

